



# Wedge Post Mount Installation Instructions



**Step 1:** Position post mount at desired post location. Note: If installing post trim set back from edge of deck/porch to allow for post trim to fit properly.

**Step 2:** Use marker to mark location of center hole to be drill in deck/porch surface.

**Step 3:** Use 1/2" drill bit (wood or masonry) depending on surface to drill hole. For concrete application drill hole approximately 3" deep. For wood/composite surface, hold 1 1/2" thick block of wood under decking.

**Step 4:** (If fastening to wood/composite surface go to step 5) Place metal plate between post mount and concrete. Drive concrete wedge anchor into concrete & tighten down until snug. Insert leveling bolts into each corner until post mount is level and plumb. Once post mount is at desired position tighten the concrete anchor until tight. \*Proceed to Step 6\*

**Step 5:** Insert Stainless Steel Carriage bolt through 1/2" hole with threads facing up. Be sure 1 1/2" wood block is placed directly under decking for added strength. Tighten carriage bolt until tight.

**Step 6:** Slide vinyl post sleeve over post tower. Use a long bar and tap the locking wedge down into the tower until the vinyl post fits snug.



Wood Hardware



Concrete Kit



[www.huskervinyl.com](http://www.huskervinyl.com)

**HUSKER VINYL, INC.**

**47287 US Hwy. 81, Humphrey, NE 68642**

**Telephone: 402-923-0323**

**Toll-Free: 866-91-VINYL (866-918-4695)**

**FAX: 402-923-0353**

**E-mail: [saleshv@huskervinyl.com](mailto:saleshv@huskervinyl.com)**